



FLEET DIRECTOR TABLET

Navigation & Messaging

User Guide





COPYRIGHT NOTICE

This is an unpublished work protected by the United States copyright laws and is proprietary to Teletrac, Inc. and its affiliates. Disclosure, copying, reproduction, merger, translation, modification, enhancement or use by anyone other than authorized employees or licensees of Teletrac, Inc. and its affiliates without the prior written consent of Teletrac, Inc. and its affiliates is prohibited.

This copyright notice should not be construed as evidence of publication.

DISCLAIMER

Teletrac, Inc. and its affiliates make a genuine effort to ensure the accuracy and quality of these materials. However, Teletrac, Inc. and its affiliates make no warranty whatsoever, express or implied, with respect to the completeness or accuracy of the contents herein and accepts no liability of any kind including (but not limited to) performance, merchantability, fitness for any particular purpose, or any losses or damages of any kind caused or alleged to be caused directly or indirectly from this document.

TRADEMARK NOTICES

Fleet Director® is a registered trademark of Teletrac, Inc.

Copyright © 2015 Teletrac, Inc.

All Rights Reserved

Teletrac, Inc.

7391 Lincoln Way

Garden Grove, CA 92841

www.teletrac.com

1.800.TELETRAC


TABLE OF CONTENTS


Introduction	1
Message Indicator.....	1
Messaging Icons.....	1
Viewing a Message.....	2
Create and Send Messages	3
Types of Messages.....	3
Sending Canned Messages.....	3
Sending Form-Fill Messages.....	4
Sending Free-Text Messages.....	5
Navigation	6
Setting a Home Address.....	6
Navigating to an Address.....	7
Navigating to a Location Stored in History.....	8
Navigating to a Point on the Map.....	9
Navigating to GPS Coordinates.....	10
GPS Coordinates Using Decimal.....	10
GPS Coordinates Using Degree, Minutes and Seconds.....	11
Adding a Location to Favorites.....	12
Navigating to a Location in Favorites.....	13
Viewing Active Routes.....	14
Viewing Blocked Roads.....	14
Stopping Navigation.....	15
Muting Navigation.....	15
Tablet Settings	16
Adjusting Volume and Brightness.....	16
Adjusting Navigation Routing or Settings.....	16
Adjusting Display Settings.....	16

INTRODUCTION

The Fleet Director Tablet allows drivers to send and receive messages using a QWERTY keyboard via a color touch screen, in addition to supporting a full-featured Turn-By-Turn (TBT) navigation. This guide shows how to use the messaging and navigation functions of the Tablet.






MESSAGE INDICATOR

The envelope icon  on the right of the screen notifies a driver when a message has been received by doing the following:

-  This helpful icon shows (numerically on the top right) how many messages have been received by the Tablet. In addition, a beep sound quickly alerts the Driver that new messages are waiting in the messaging inbox. The beep repeats every 30 seconds until the Driver reviews the messages.



MESSAGING ICONS



Users will find these messaging icons when viewing or creating messages on the Tablet.

Messaging Icons	
	To view the first and previous message page.
	To view the next message page(s).
	To delete the current message.
	To save the message shown.
	To exit the Messaging screen and return to the Inbox .

VIEWING A MESSAGE

Quickly view incoming messages on the Tablet.

Viewing a Message	
Step 1	Touch  . The Message Inbox screen appears. The Tablet displays the most recent messages first (top to bottom).
Step 2	Touch any one message to highlight your selection. Touch  . The View Message window appears. At this point, Drivers can view the entire message and scroll down (if necessary). (See Note .)
Step 3	Touch Save to save the message or touch Delete to delete.

Note: Some messages may be six lines or more. To view the entire message, touch  or  to scroll up or scroll down while viewing the message contents.

CREATE AND SEND MESSAGES

TYPES OF MESSAGES*







Drivers have the ability to send three types of messages from the Tablet:

- **Canned Messages** – Pre-installed messages that do not require data entry before sending. These messages are the most common type of message sent by a driver to dispatch and are either default or custom, based on a company's business needs. Useful for quick work updates and two-way messaging.
- **Form-Fill Messages** – Template-based messages that ask Drivers to enter information into available fields. These messages can be used to send delivery and pick up information, such as a stop number, parcels picked up or delivered, weight of parcel and time of pick up, depending on the available fields.
- **Free-Text Messages** – Messages that allow Drivers to include up to 500 characters in free form. This option is useful for detailed messages.

*Canned and Form-Fill messages can be customized via the Teletrac system.











SENDING CANNED MESSAGES

The following shows Drivers how to send pre-set Canned messages via the Tablet at any time.

Sending a Canned Message	
Step 1	From the right side menu, touch  . This opens the Messaging Inbox .
Step 2	Touch Canned messages  .
Step 3	Touch the message to highlight your selection or use  and  to scroll through the message pages to search.
Step 4	Touch  . The "Confirm Canned Message" screen appears.
Step 5	Touch  to send the message.







SENDING FORM-FILL MESSAGES

The following shows Drivers how to send template-based Form-Fill messages via the Tablet at any time.

Sending a Form-Fill Message	
Step 1	From the right side menu, touch  . This opens the Messaging Inbox .
Step 2	Touch Form Messages  .
Step 3	Touch the message to highlight your selection or use  and  to scroll through the message pages to search.
Step 4	Touch  to retrieve the message. The Form-Fill message appears with brackets where you can enter information.
Step 5	Use the  or  to move the bracket to a field. Touch anywhere in the message: the keyboard appears. Enter the information you want to send. Note: Information entered applies only to the bracketed field regardless of where the user touches within the message.
Step 6	Touch  to send the message. This sends you back to the Form Message screen. Note: If your form has more than one field, use the  and  to move to the next or previous field. Repeat step 5 for additional entries.

SENDING FREE-TEXT MESSAGES

The following shows Drivers how to send detailed Free-Text messages (up to 500 characters) via the Tablet at any time.






Sending a Free-Text Message	
Step 1	From right side menu, touch  . This opens the Messaging Inbox .
Step 2	Touch Form Messages  .
Step 3	Use  and  to scroll and find the FREE TEXT option. Touch the message to highlight it and then touch  . This takes you to the Edit Message screen.
Step 4	Touch the message box. The QWERTY keyboard appears. Enter your characters.
Step 5	Touch  to send the message.

NAVIGATION

This section shows Drivers how to launch the turn-by-turn navigation application, navigate to an address or Point of Interest (POI), navigate to locations saved in the history, and how to save and navigate to locations in Favorites.




SETTING A HOME ADDRESS

Quickly set up a home address to instantly navigate to the “home” location, such as headquarters or a frequent customer location, from any travel point, at any time.

Setting a Home Address	
Step 1	Touch Navigation .
Step 2	Touch any location on the map. The Navigation options appear.
Step 3	Touch Navigate To .
Step 4	Touch Home in the Navigate To screen. The Home Settings screen appears.
Step 5	Touch  to enter your address.
Step 6	From the City tab, enter the entire city or ZIP code. You may enter the first two/three letters/numbers of the city or ZIP and touch the orange drop-down arrow (if active) to select from a list. When complete, touch  .
Step 7	From the Road (street) tab, enter the entire street name. You may enter the first two/three letters of the street name and touch the orange drop-down arrow (if active) to select from the list. When complete, touch  . Note: To edit the city, touch the City tab.
Step 8	From the Road Number tab, enter the address number. When complete, touch  . Note: To edit the city or the street, touch the City or the Road tab.
Step 9	Touch  to return to the Navigate To screen.

NAVIGATING TO AN ADDRESS

Quickly navigate to a targeted address at any time.

Navigating to an Address	
Step 1	Touch Navigation .
Step 2	Touch any location on the map.
Step 3	Touch Navigate To .
Step 4	Touch Address .
Step 5	From the City tab, enter the entire city or ZIP code. You may enter the first two/three letters/numbers of the city or ZIP and touch the orange drop-down arrow (if active) to select from a list. When complete, touch  .
Step 6	Touch the Road (street) tab and enter the entire street name. You may enter the first two/three letters of the street name and touch the orange drop-down arrow (if active) to select from the list. When complete, touch  . Note: To edit the city, touch the City tab.
Step 7	From the Road Number tab, enter the address number. When complete, touch  . The Launch Navigation screen appears. <i>At this point, touch the middle icon to change the default route settings to one of the following:</i> <ul style="list-style-type: none"> • Shortest time • No Toll • No Highway • Shortest way • No Highway and No Toll <i>Touch the Vehicle icon to change the vehicle type.</i> Note: To edit the city or the street, touch the City or the Road tab.
Step 8	Once you have selected an address, touch either X to cancel your selection or touch Go to navigate to the address.

NAVIGATING TO A LOCATION STORED IN HISTORY

Quickly navigate to a previous location traveled, at any time.

Navigating to a Location Stored in History	
Step 1	Touch Navigation .
Step 2	Touch any location on the map.
Step 3	Touch Navigate To .
Step 4	Touch History .
Step 5	Touch an address in the History list. Then touch Go . The Launch Navigation screen appears. <i>At this point, touch the middle icon to change the default route settings to one of the following:</i> <ul style="list-style-type: none"> • Shortest time • No Toll • No Highway • Shortest way • No Highway and No Toll <i>Touch the Vehicle icon to change the vehicle type.</i>
Step 6	Once you have selected an address, touch either X to cancel your selection or touch Go to navigate to the previously used address.

NAVIGATING TO A POINT ON THE MAP

Quickly navigate to a specific point on the map, at any time.



Navigating to a Point on the Map	
Step 1	Touch Navigation .
Step 2	Touch any location on the map.
Step 3	Touch Navigate To .
Step 4	Touch Point on map . The map screen appears.
Step 5	Touch the + or - keys to adjust the zoom level.
Step 6	Swipe one or two fingers up, down, right, or left to adjust the placement of the location on the map.
Step 7	<p>When you find the location, tap the Tablet screen in the desired place, and then touch Go. The Launch Navigation screen appears.</p> <p><i>At this point, touch the middle icon to change the default route settings to one of the following:</i></p> <ul style="list-style-type: none"> • <i>Shortest time</i> • <i>No Toll</i> • <i>No Highway</i> • <i>Shortest way</i> • <i>No Highway and No Toll</i> <p><i>Touch the Vehicle icon to change the vehicle type.</i></p>
Step 8	Once you have selected an address, touch either X to cancel your selection or touch Go to navigate to the point on the map.

NAVIGATING TO GPS COORDINATES

Quickly enter GPS coordinates (latitude/longitude by using a decimal or minutes, degree and seconds) and navigate to the location, at any time.







GPS Coordinates Using Decimal

Note: Drivers must have exact latitude/longitude coordinates for a precise navigation. The **GO** icon will not highlight if values entered are invalid.

Navigating to a GPS Coordinate Using Decimal	
Step 1	Touch Navigation .
Step 2	Touch any location on the map.
Step 3	Touch Navigate To .
Step 4	Touch GPS Coordinates . The GPS Coordinates screen appears.
Step 5	Below the GPS Coordinates header, touch the 0.0000 option.
Step 6	Touch the Latitude bar. The numeric keypad appears. Enter the value, including the decimal. When complete, touch  .
Step 7	Touch the Longitude box. The numeric keypad appears. Enter the value, including the decimal. When complete, touch  .
Step 8	<p>Touch Go. The Launch Navigation screen appears.</p> <p><i>At this point, touch the middle icon to change the default route settings to one of the following:</i></p> <ul style="list-style-type: none"> • <i>Shortest time</i> • <i>No Toll</i> • <i>No Highway</i> • <i>Shortest way</i> • <i>No Highway and No Toll</i> <p><i>Touch the Vehicle icon to change the vehicle type.</i></p>
Step 9	Once you have selected your settings, touch either X to cancel your selection or touch Go to navigate to your location (decimal coordinates).




GPS Coordinates Using Degree, Minutes And Seconds

Note: Drivers must have exact latitude/longitude coordinates for a precise navigation. The **GO** icon will not highlight if values entered are invalid.

Navigating to a GPS Coordinate Using Degree, Minutes and Seconds	
Step 1	Touch Navigation .
Step 2	Touch any location on the map.
Step 3	Touch Navigate To .
Step 4	Touch GPS Coordinates . The GPS Coordinates screen appears.
Step 5	Below the GPS Coordinates header, touch the 0°0'0" option.
Step 6	Touch below Latitude to change from North to South . Touch the Degree (°) box. The numeric keypad appears. Enter the value. When complete, touch  .
Step 7	Touch the Minutes (') box. The numeric keypad appears. Enter the value. When complete, touch  .
Step 8	Touch the Seconds (") box. The numeric keypad appears. Enter the value. When complete, touch  .
Step 9	Touch below Longitude to change from East to West . Touch the Degree (°) box. The numeric keypad appears. Enter the value. When complete, touch  .
Step 10	Touch the Minutes (') box. The numeric keypad appears. Enter the value. When complete, touch  .
Step 11	Touch the Seconds (") box. The numeric keypad appears. Enter the value. When complete, touch  .
Step 12	Touch Go . The Launch Navigation screen appears. <i>At this point, touch the middle icon to change the default route settings to one of the following:</i> <ul style="list-style-type: none"> • Shortest time • No Highway • No Highway and No Toll • No Toll • Shortest way <i>Touch the Vehicle icon to change the vehicle type.</i>
Step 13	Once you have selected your settings, touch either X to cancel your selection or touch Go to navigate to your location.

ADDING A LOCATION TO FAVORITES

Quickly add locations to your Favorites for a fast and easy search.

Adding a Location to Favorites	
Step 1	Touch Navigation .
Step 2	Touch any location on the map.
Step 3	Touch Navigate To .
Step 4	Touch History .
Step 5	Touch an address in the History list and then touch the star icon . The keyboard appears.
Step 6	Enter a unique name for this location. When complete, touch  . Your entry is saved in Favorites .
Step 7	Touch  to return the History list screen.
Step 8	Touch  to return to the Navigate To screen.



NAVIGATING TO A LOCATION IN FAVORITES

Quickly navigate to locations listed as Favorites at any time.

Navigating to a Location in Favorites	
Step 1	Touch Navigation .
Step 2	Touch any location on the map.
Step 3	Touch Navigate To .
Step 4	Touch Favorites . The Favorites list appears.
Step 5	<p>Touch a location in the Favorites list. Then touch Go. The Launch Navigation screen will appear.</p> <p><i>At this point, touch the middle icon to change the default route settings to one of the following:</i></p> <ul style="list-style-type: none"> • <i>Shortest time</i> • <i>No Toll</i> • <i>No Highway</i> • <i>Shortest way</i> • <i>No Highway and No Toll</i> <p><i>Touch the Vehicle icon to change the vehicle type.</i></p>
Step 6	Once you have selected your settings, touch X to cancel your selection or touch Go to navigate to your Favorites location.

VIEWING ACTIVE ROUTES

Quickly view the remaining distance of the active route from the most recent travel point on the navigation map.

Viewing an Active Route	
Step 1	Touch Navigation .
Step 2	Touch any location on the map. The Navigation screen appears.
Step 3	Touch Map Explorer . The map shows the remainder of the active route.
Step 4	Touch  to return the Navigation screen.
Step 5	Touch  to return to the map screen.

Viewing Blocked Roads

Quickly view and avoid blocked roads.

Viewing Blocked Roads	
Step 1	Touch Navigation .
Step 2	Touch any location on the map. The Navigation screen appears.
Step 3	Touch Blocked road . The Avoid road on... screen appears with each segment of the route.
Step 4	<p>Touch the appropriate segment you want to avoid.</p> <p>Note: <i>The Tablet automatically recalculates the route, redirecting you away from the current road to an alternate route.</i></p>


STOPPING NAVIGATION

Quickly stop any current or ongoing navigation.

Stopping Navigation	
Step 1	Touch Navigation or touch anywhere in the navigation map. The Navigation screens appears.
Step 2	Touch Stop Navigation . Navigation stops.

MUTING NAVIGATION

Quickly mute voice-guided navigation.



Muting Navigation	
Step 1	Touch Navigation .
Step 2	Touch any location on the map. The Navigation screens appears.
Step 3	Touch Mute . Note: To unmute, touch Mute again.
Step 4	Touch  to return to the map screen.

TABLET SETTINGS

The following shows how to access the general settings for navigation and how to configure them.


ADJUSTING VOLUME AND BRIGHTNESS

To begin, touch **Apps**  then **Settings** :

Adjusting Volume and Brightness	
Step 1	Touch Settings  in the Settings screen. The Settings/General screen appears.
Step 2	In the Sound bar, touch + or - to set the volume level.
Step 3	In the Brightness , touch + or - to set the brightness level. Note: To return to Apps , touch  on the bottom right of the screen.



ADJUSTING NAVIGATION ROUTING OR SETTINGS

To begin, touch **Apps**  then **Settings** :

Adjusting Navigation Routing	
Step 1	Touch Settings  in the Settings screen. The Settings/General screen appears.
Step 2	Touch the Other Parameters bar. A Settings:General screen appears.
Step 3	Adjust settings as required, such as vehicle height, length, weight, hazardous cargo and maximum speed.

ADJUSTING NAVIGATION DISPLAY SETTINGS

To begin, touch **Apps**  then **Settings** :

Adjusting Navigation Display Settings	
Step 1	Touch Settings  in the Settings screen. The Settings/General screen appears.
Step 2	Go to Applications at the bottom of the screen and touch  . The Settings:Navigation screen appears. Swipe one or two fingers to scroll up and down to find your settings.
Step 3	Adjust settings as required, such as audible and visual alerts for speeding, lane guidance and 2D/3D map view.



Help Desk
1.800.ITS.HELP